


Mat. – Nr. – Konstante
3740


Gebrauchsanweisung
59 1146
(RU)

42 4983
(RU)



Mat. - Nr. - Konstante
3740


1) 35 5528



Mat. - Nr. - Konstante
3740

1) 26 5964

Mat. – Nr. – Konstante
3740



Position ID	Spare part no.	Replacement	Description
0001	00067332	00621463	Foot
0002	00084713	00655300	Holder
0003	00141874	00145787	Pump-drain
0004	00142369	00145563	Motor
0005	00167581		Holder
0006	00167587	00067083	Holder
0007	00170961		Sensor-NTC
0008	00171253	00481580	Power cord
0009	00171254	00623842	Capacitor-interference suppre.
0010	00171261	00428210	Valve-magnet
0011	00171270		Screw
0012	00171271		Screw
0013	00171272		Fixture
0014	00171273		Holder
0015	00171275	00606818	Spring-tank
0016	00172394	00421488	fastening ring
0017	00172395	00603523	fastening ring
0018	00172688	00448032	Shock absorber
0019	00172692	00613083	Shaft seal
0020	00172699		Knob-programme
0021	00172700		Knob-RPM
0022	00181184		Hose-vent
0023	00182154		Electric lock
0024	00182194		Lid
0025	00182429		Nut
0026	00186869	00429205	Transit bolt
0027	00186870		Transit bolt

0029	00188918	00427040	Regulator-water level
0030	00214720		Weight
0031	00215114	00475501	Weight
0032	00218343		Worktop
0033	00235502	00241627	Tub
0034	00235567		Front panel
0035	00236611	00215117	Drum
0036	00238921		Tub at rear
0037	00241219	00711567	Housing
0038	00265958		Hose-fill
0039	00265961		Heating element
0040	00265964		Sealing
0041	00266748	00267678	Tray handle-dispenser
0042	00266752		Cover
0043	00266859	12013467	Hose-inlet
0044	00268663		Clamp
0046	00354126	00439671	fastening ring
0047	00354130	11002942	Pulley
0048	00354131	00678914	Belt-drive
0049	00354134		fastening ring
0050	00354135		Boot gasket
0052	00358304		Container return
0053	00358305		Hose
0054	00358306		Outlet hose
0055	00358923		Rail
0056	00358931	00435791	Rail
0058	00355529		Window
0060	00436816		Case-rear part
0063	00354129	00366232	Frame-window

0064	00354127	00715042	Ring
0065	00354128	11020392	Window
0066	00266751		Handle
0067	00171255		Axis
0068	00171264		Bushing
0069	00171269		Hinge-window
0070	00171278	00634207	Latch
0071	00354123		Dispenser tray
0072	00354122		Dispenser tray-lower part
0073	00265957		Dispenser tray-upper part
0074	00423704		Cable harness
0075	00423938		Cable harness
0076	00423939		Cable harness
0077	00423940		Cable harness
0079	00423701		Cable harness
0080	00423702		Cable harness