



Mat. - Nr. - Konstante  
3740 . . . . .

Gebrauchsanweisung  
59 1020  
(DE)




Mat. - Nr. - Konstante  
3740 . . . . .

- 1) 35 5528
- 2) 18 6869
- 3) 18 6870



Mat. - Nr. - Konstante  
3740 . . . . .

1) 26 5964  
Set



Mat. - Nr. - Konstante  
3740 . . . . .

	ASKOLL	COPRECI
1	17 2340	17 2337
2	15 1408	15 4358
3	_____	172338
4	15 1409	_____
5	_____	17 2339

<b>Position ID</b>	<b>Spare part no.</b>	<b>Replacement</b>	<b>Description</b>
0001	00067332	00621463	Foot
0002	00084713	00655300	Holder
0003	00142369	00145563	Motor
0004	00141874	00145787	Pump-drain
0005	00163750		Ball bearing
0007	00167581		Holder
0008	00167587	00067083	Holder
0009	00170961		Sensor-NTC
0010	00171253	00481580	Power cord
0011	00171254	00623842	Capacitor-interference suppre.
0012	00171261	00428210	Valve-magnet
0013	00171270		Screw
0014	00171271		Screw
0015	00171272		Fixture
0016	00171273		Holder
0017	00171275	00606818	Spring-tank
0018	00172692	00613083	Shaft seal
0019	00172394	00421488	fastening ring
0020	00172395	00603523	fastening ring
0021	00172688	00448032	Shock absorber
0023	00426992	00603514	Electric lock
0024	00182194		Lid
0025	00186869	00429205	Transit bolt
0026	00186870		Transit bolt
0028	00214720		Weight
0029	00215114	00475501	Weight
0030	00236611	00215117	Drum

0031	00218343		Worktop
0032	00235502	00241627	Tub
0033	00235567		Front panel
0034	00235500		Tub at rear
0035	00241219	00711567	Housing
0036	00265958		Hose-fill
0037	00265961		Heating element
0038	00265965		Band
0039	00266752		Cover
0040	00266859	12013467	Hose-inlet
0041	00289822		Support
0042	00354126	00439671	fastening ring
0043	00354130	11002942	Pulley
0044	00354134		fastening ring
0045	00354135		Boot gasket
0051	00358923		Rail
0052	00358931	00435791	Rail
0053	00354131	00678914	Belt-drive
0055	00436816		Case-rear part
0056	00265964		Sealing
0057	00355529		Window
0058	00354129	00366232	Frame-window
0059	00354127	00715042	Ring
0060	00354128	11020392	Window
0061	00266751		Handle
0062	00171255		Axis
0063	00171264		Bushing
0064	00171269		Hinge-window
0065	00171278	00634207	Latch

0067	00354123		Dispenser tray
0068	00354122		Dispenser tray-lower part
0069	00265957		Dispenser tray-upper part
0070	00438749	00443356	Control module
0071	00266748	00267678	Tray handle-dispenser
0072	00188918	00427040	Regulator-water level
0073	00423704		Cable harness
0074	00423938		Cable harness
0075	00423939		Cable harness
0076	00423940		Cable harness
0078	00423701		Cable harness
0079	00423702		Cable harness
0080	00172699		Knob-programme
0081	00172700		Knob-RPM