


Mat. - Nr. - Konstante  
 3740 . . . . .


Gebrauchsanweisung  
 59 5530  
 (DE)

- 1) 42 3941  
 V01  
 60 0110  
 V02,V03
- 2) 17 1254  
 V01,V02  
 60 3267  
 V03



Mat. - Nr. - Konstante  
 3740 . . . . .


- 1) 35 5528
- 2) 18 6869
- 3) 18 6870



Mat. - Nr. - Konstante  
 3740 . . . . .

1) 26 5964  
 Set

Mat. - Nr. - Konstante  
3740 . . . . .



	ASKOLL	COPRECI
1	17 2340	17 2337
2	15 1408	15 4358
3	_____	172338
4	15 1409	_____
5	_____	17 2339

<b>Position ID</b>	<b>Spare part no.</b>	<b>Replacement</b>	<b>Description</b>
0010	00067332	00621463	Foot
0020	00068337		Holder
0030	00084713	00655300	Holder
0040	00141874	00145787	Pump-drain
0050	00141875	00144797	Motor
0060	00150871		Terminal
0070	00163750		Ball bearing
0100	00167581		Holder
0110	00167587	00067083	Holder
0120	00170961		Sensor-NTC
0130	00171253	00481580	Power cord
0140	00171261	00428210	Valve-magnet
0150	00171270		Screw
0160	00171271		Screw
0170	00171272		Fixture
0180	00171273		Holder
0190	00172394	00421488	fastening ring
0200	00172395	00603523	fastening ring
0210	00172697		Coupling
0220	00172698		Coupling
0230	00172699		Knob-programme
0240	00172700		Knob-RPM
0250	00182194		Lid
0260	00186869	00429205	Transit bolt
0270	00186870		Transit bolt
0290	00214720		Weight
0300	00214721	00773470	Weight

0310	00215113	00773699	Drum
0320	00218343		Worktop
0330	00235499	00714215	Tub at rear
0340	00235501	00715100	Tub
0350	00235567		Front panel
0360	00241219	00711567	Housing
0370	00265958		Hose-fill
0380	00265961		Heating element
0390	00265965		Band
0400	00266752		Cover
0420	00354124		Outlet hose
0430	00354130	11002942	Pulley
0440	00354134		fastening ring
0450	00354135		Boot gasket
0480	00355529		Window
0490	00358923		Rail
0500	00358931	00435791	Rail
0510	00360829	00439490	Belt-drive
0520	00423701		Cable harness
0530	00423702		Cable harness
0540	00423704		Cable harness
0550	00423938		Cable harness
0560	00423939		Cable harness
0570	00423940		Cable harness
0590	00426992	00603514	Electric lock
0600	00434099		Rail
0610	00436816		Case-rear part
0620	00460766	11007861	Aquasecure
0630	00172688	00448032	Shock absorber

0640	00171291	00613082	Shaft seal
0650	00480442		Eco-hose-sump
0670	00427040		Regulator-water level
0690	00443352		Control module
0700	00366232		Frame-window
0710	00432073		Ring
0720	00354128	11020392	Window
0730	00266751		Handle
0740	00171255		Axis
0750	00171264		Bushing
0760	00171269		Hinge-window
0770	00181984	00634207	Latch
0780	00354123		Dispenser tray
0790	00354122		Dispenser tray-lower part
0800	00265957		Dispenser tray-upper part
0810	00172699		Knob-programme
0820	00172700		Knob-RPM